

















Cisco 7900 Series Phone Button Layout



Cisco Unified IP Phone 7941G and 7941G-GE



	Item	Description
1	Programmable buttons 	Depending on configuration, programmable buttons provide access to: <ul style="list-style-type: none"> • Phone lines (line buttons) and intercom lines • Speed-dial numbers (speed-dial buttons, including the BLF speed-dial feature) • Web-based services (for example, a Personal Address Book button) • Call features (for example, a Privacy, Hold, or Transfer button) Buttons illuminate to indicate status: <ul style="list-style-type: none">  Green, steady—Active call or two-way intercom call  Green, flashing—Held call  Amber, steady—Privacy in use, one-way intercom call, DND active, or logged into Hunt Groups  Amber, flashing—Incoming call or reverting call  Red, steady—Remote line in use (shared line, BLF status or active Mobile Connect call)
2	Phone screen	Shows call features.
3	Footstand button	Allows you to adjust the angle of the phone base.
4	Messages button 	Auto-dials your voice message service (varies by service).
5	Directories button 	Opens/closes the Directories menu. Use it to access call logs and directories.
6	Help button 	Activates the Help menu.

	Item	Description
7	Settings button 	Opens/closes the Settings menu. Use it to control phone screen contrast and ring sounds.
8	Services button 	Opens/closes the Services menu.
9	Volume button	Controls the handset, headset, and speakerphone volume (off-hook) and the ringer volume (on-hook).
10	Speaker button 	Toggles the speakerphone on or off. When the speakerphone is on, the button is lit.
11	Mute button 	Toggles the microphone on or off. When the microphone is muted, the button is lit.
12	Headset button 	Toggles the headset on or off. When the headset is on, the button is lit.
13	Navigation button 	Allows you to scroll through menus and highlight items. When the phone is on-hook, displays phone numbers from your Placed Calls log.
14	Keypad	Allows you to dial phone numbers, enter letters, and choose menu items.
15	Softkey buttons 	Each activates a softkey option (displayed on your phone screen).
16	Handset light strip	Indicates an incoming call or new voice message.