PHODUCT: Acctylene

L-4559-E April 1987

# VIILSPECIAL PROTECTION INFORMATION

RESPIRATORY PROTECTION (specify type) — Use respirable fume respirator or air supplied respirator when working in confined space or where local exhaust or ventilation does not keep exposure below TLV. Select as per OSHA29 CFR1910.134.

	LOCAL EXHAUST — Use enough ventilation, local exhaust or both, to keep the fumes and gases below TLV's in the worker's breathing zone and the general area. Train the worker to keep his head out of the fumes.				
	MECHANICAL (general)	ALWAYS WORK WITH ENOUGH VENTILATION			
PENTILATION					
	SPECIAL	Not applicable			
	OTHER Depends on specific use conditions, and location. Use adequate ventilation or personal respiratory protection. See Section IX and OSHA29 CFR1910.252.				

PROTECTIVE GLOVES

Welding gloves recommended

EYE PROTECTION — Wear goggles with filter lens selected as per ANSI Z49.1. Provide protective screens and goggles, if necessary, to protect others. Select as per OSHA29 CFR1910.133.

OTHER PROTECTIVE EQUIPMENT — As needed, wear hand, head, and body protection which help to prevent injury from radiation and sparks. See ANSI Z49.1. At a minimum this includes welder's gloves and protective goggles, and may include arm protectors, aprons, hats, shoulder protection, as well as substantial clothing. Train the worker not to touch live electrical parts.

# IX.SPECIAL PRECAUTIONS

Fumes and gases cannot be classified simply. The composition and quantity of both are dependent upon the metal being worked, the process, procedure and electrodes used. Other conditions which also influence the composition and quantity of the fumes and gases to which workers may be exposed include; coatings on the metal being worked (such as paint, plating, or galvanizing), the number of workers and the volume of the work area, the quality and amount of ventilation, the position of the worker's head with respect to the fume plume, as well as the presence of contaminants in the atmosphere (such as chlorinated hydrocarbon vapors from cleaning and degreesing activities).

One recommended way to determine the composition and quantity of furnes and gases to which workers are exposed is to take an air sample from inside the worker's helmet if wom or in the worker's breathing zone. See ANSI/AWS F1.1, available from the American Welding Society, 550 N.W. Le Jeune Rd., Miami, FL 33126.

Read and understand the manufacturer's instructions and the precautionary label on the product. See American National Standard Z49.1, "Safety in Welding And Cutting" published by the American Welding Society and OSHA Publication 2206 (29CFR1910), U.S. Government Printing Office, Washington, D.C. 20402 for more details. For further safety and health information refer to Linde's free safety booklet L-2035.

OTHER HANDLING AND STORAGE CONDITIONS

Heat and sparks during use could be the source of ignition of combustible materials. Prevent fires.

Refer to NFPA 51B "Cutting and Welding Processes" and NFPA 50 "Oxygen-Fuel Gas Systems." Use piping and equipment adequately designed to withstand pressures to be encountered. Gas can cause rapid suffocation due to oxygen deficiency. Store and use with adequate ventilation. Close valve when not in use and when empty. Never work on a pressurized system. Do not strike arc on cylinder. The defect produced by an arc burn could lead to cylinder rupture. Do not ground cylinder. Store in cool, dry, well ventilated area. Do not store near open flames. Electrical equipment should be explosion proof. Do not store with oxygen or other oxidizers. Protect cylinders from physical damage. Store cylinders in upright position secured to prevent falling over. Refer to CGA Pamphlets P-1 and G-1 for recommendations.

The opinions expressed herein are those of qualified experts within Union Carbide. We believe that the information contained herein is current as of the date of this Material Safety Data Sheet. Since the use of this information and these opinions and the conditions of use of the product are not within the control of Union Carbide, it is the user's obligation to determine the conditions of safe use of the product.



**GENERAL OFFICES** 

IN THE USA: Union Carbide Corporation

Linde Division

39 Old Ridgebury Road Danbury, CT 06817-0001 IN CANADA: Union Carbide Canada Limited

Linde Division 123 Eglinton Avenue East Toronto, Ontario M4P U3

Other offices in principal cities all over the world.

L-4559-E 87-0928 4/87 30M

Lithographed In U.S.A.

Page 4 of 4

# MATERIAL SAFETY DATA SHEET



stansion of the terms used herein may be found in OSHA 29 CFR 1910.1200, available from OSHA regional or area offices.

(Similar to U.S. Department of Labor Form OMB No. 121s-0072 and generally accepted in Canada for Information purposes) Do Not Duplicate This Form. Request an Original.



# 全に、「「A Marian Annual Annual

PRODUCT	Acetylene		
CHEMICAL NAME	Acetylene	SYNONYMS	Acetylen, Ethine, Ethyne, Narcylene
FORMULA	C <sub>2</sub> H <sub>2</sub>	CHEMICAL FAMILY	Alkyme
		MOLECULAR WEIGHT	26.038

TRADE NAME Acetylene (This product is intended for welding and cutting use,)

# A LAND THE REPORT OF THE PROPERTY OF THE PROPE

This section covers the materials from which this product is manufactured. The fumes and gases produced during welding and cutting with the normal use of this product are covered by Section VI. The term "hazardous" should be interpreted as a term required and defined in OSHA 29 CFR 1910.1200 and does not necessarily imply the existence of any hazard.

MATERIAL (CAS NO.)	Vol (%)	1986-1987 ACQIH TL	V-TWA (OSHA-PEL)
Acetylene (74-86-2)	100	Simple asphysiant	(None currently established)
		containing acetone into	re filled with a porous material owhich the acetylene is dissolved. a TLV-TWA of 750 ppm for acetone pm.

BOILING POINT, 760 mm. Hg	Not Applicable	SUBLIMATION POINT	-84°C (-119.2°F) @ 760mm Hç
SPECIFIC GRAVITY (H <sub>2</sub> O = 1)	Not Applicable	VAPOR PRESSURE AT 21°C.	635 psig
VAPOR DENSITY (air = 1)	0.91	SOLUBILITY IN WATER, % by wt.	Slight
PERCENT VOLATILES BY VOLUME	100	EVAPORATION RATE (Butyl Acetate = 1)	Not Applicable

APPEARANCE AND ODOR Colorless gas at normal temperature and pressure; gartic-like odor.

# EMERGENCY PHONE NUMBER

IN CASE OF EMERGENCIES involving this material, further information is available at all times: in the USA 1-800-UCC-HELP (1-800-822-4357) In Canada 514-645-6311

For routine information contact your local supplier

Union Carbide requests the users of this product to study this Material Safety Data Sheet (MSDS) and become aware of product hazards and safety information. To promote safe use of this product a user should (1) notify its employees, agents and contractors of the Information on this MSDS and any product hazards and safety information. (2) furnish this same information to each of its customers for the product, and (3) request such customers to notify their employees and customers for the product of the same product hazards and safety information.

UNION CARBIDE CORPORATION | LINDE DIVISION UNION CARBIDE CANADA LIMITED | LINDE DIVISION

Copyright © 1985, 1986, 1987 Union Carbide Corporation

Page 1 of 4

# IV. HEALTH HAZARD DATA

1 A 1 25

THRESHOLD LIMIT VALUE: Acatylene - Simple asphyxiant ACGIH 1996-87; Acatone, 750ppm ACGIH 1988-87

### **EFFECTS OF SINGLE (ACUTE) OVEREXPOSURE**

SWALLOWING — An unlikely route of exposure, but frostbite of the lips and mouth may result from contact with the liquid. If the liquid is swallowed, may cause nausea.

SKIN ABSORPTION -- No evidence of adverse effects from available information.

INHALATION -- Asphydent. Moderate concentrations of vapor may cause headache, drowsiness, dizziness, nausea, vomiting, excitation, encess salivation, and unconsciousness.

SKIN CONTACT - No harmful effects expected from vapor. Liquid may cause frostbite.

EYE CONTACT - Vapor may cause inflation. Liquid may cause inflation and frostbite.

EFFECTS OF REPEATED (CHRONIC) OVEREXPOSURE: No evidence of adverse effects from available information.

OTHER EFFECTS OF OVEREXPOSURE: None currently known.

MEDICAL CONDITIONS AGGRAVATED BY OVEREXPOSURE: A knowledge of the available toxicology information and of the physical and chemical properties of the material suggest that overexposure is unlikely to aggrevate existing medical conditions.

### **EMERGENCY AND FIRST AID PROCEDURES:**

SWALLOWING -- If liquid is swellowed, do not induce vomiting. Call a physician.

SKIN -- For exposure to liquid, flush with water and warm frostbite area with warm water (not to exceed 105°F). In case of massive exposure, remove clothing while showering with warm water. Call a physician.

INHALATION - Remove to freeh air. If breathing has stopped, give artificial respiration; if breathing is difficult, oxygen may be Civen: cell a physicien

EYES - In case of apleah contamination, immediately flush eyes thoroughly with water for at least 15 minutes. Seek the advice of a physician, preferably an ophthalmologist, urgently.

NOTES TO PYTSICIAN: Aspirated acotone may cause severe lung damage. If a large quantity of material has been swallowed, stornach contents should be evacuated quickly in a manner which avoids aspiration. Otherwise, treatment should be directed at the control of symptoms and the clinical condition. No specific antidote is known.

working with welding and cutting may create additional health hazards.

FUMES AND GASES can be dangerous to your health and may cause serious lung disease."

Keep your head out of the furnes. Do not breathe furnes and gases caused by the process. Use enough ventilation, local exhaust, or both to keep furnee and gases from your breathing zone and the general area. The type and amount of furnes and gases depend on the equipment and supplies used. Possibly dangerous materials may be found in fluxes, coatings, gases, metals etc. Get a Material Salety Data Sheet (MSDS) for every material used. Air samples can be used to find out what respiratory protection is needed.

Short term overexposure to fumes may result in discomfort such as dizziness, nauses, or dryness or irritation of nose, throat, or eyes.

Acute

-Gases, fumes, and dusts may cause irritation to the eyes, lungs, nose, and throat. Some toxic gases associated with wisiding and related processes may cause pulmonary edema, asphyxiation, and death. Acute overexposure may include signs and symptoms such as watery eyes, nose and throat irritation, headache, dizziness, difficulty breathing, frequent

Chronic -- Protracted inhelation of air contaminants may lead to their accumulation in the lungs, a condition which may be seen as dense areas on cheat x-rays. The severity of change is proportional to the length of exposure. The changes seen are not necessarily associated with symptoms or signs of reduced lung function or disease. In addition, the changes on x-rays may be caused by non-work related factors such as smoking, etc.

A detailed description of the Health Hazards and their consequences may be found in Linde's free publication "Precautions and Safe Practices for Electric Welding and Cutting," 1.52-529, You may obtain copies from your local supplier, or by writing to Union Carbide Corporation, Linds Division, Communications Department, 39 Old Ridgebury Road, Danbury, Connecticut, 06817-0001.

MIXTURES: When two or more gases, or liquefied gases are mixed, their hazardous properties may combine to create additional, unexpected hazards. Obtain and evaluate the safety information for each component before you produce the mixture. Consult an Industrial Hygieniet, or other trained person when you make your safety evaluation of the end product. Remember, gases and liquids have properties which can cause serious injury or death.

Page 2 of 4

i siupuui. Audividie

L-4559-E April 1987

# V. FIRE AND EXPLOSION HAZARD DATA

AUTOIGNITION 299°C (571°F) TEMPERATURE UPPER 100%

FLAMMABLE LIMITS IN AIR, % by volume EXTINGUISHING MEDIA

See paragraphs below.

FLASH POINT

(test method)

### SPECIAL FIRE FIGHTING PROCEDURES

Refer to CGA pamphlet SB-4, "Handling Acetylene Cylinders in Fire Situations."

-17.8°C (0°F) T.C.C.

2,3%

LOWER

Evacuate all personnel from danger area, immediately cool containers with water scray from maximum distance taking care not to extinguish flames. Remove ignition sources if without risk. If flames are accidentally extinguished, explosive re-ignition may occur. Use self-contained breathing apparatus. Stop flow of gas if without risk while contining cooling water agray, Remove all containers from area of fire if without risk. Allow fire to burn out, On-site fire brigades must comply with OSHA 29 CFR 1910.156.

### UNUSUAL FIRE AND EXPLOSION HAZARDS

Extremely flammable gas. Forms explosive mixtures with sir and oxidizing agents. Container may rupture due to heet of fire. Do not extinguish flames due to possibility of explosive re-ignition. Flammable vapors may spread from leak, Explosive atmospheres may linear. Before entering area, especially confined areas, check atmosphere with approved explosion meter. No part of a container should be subjected to a temperature higher than 52°C (approximately 125°F). All containers are provided with a pressure relief device designed to vent contents when they are exposed to elevated temperature. Contact with copper, silver, or mercury or their alloys or halogens can cause explosion and be ignited by pilot lights, other flames, smoking, sparks, heaters, electrical equipment, static discharge or other ignition sources at locations distant from product handling point.

### VI. REACTIVITY DATA .

STABILITY		CONDITIONS TO AVOID	
unstable	STABLE	Stable as shipped. Avoid use at pressures above	15 psig.
х			

# INCOMPATIBILITY (materials to avoid)

Copper, silver, mercury or their alloys, oxidizing agents, acids, halogens, moisture.

# HAZARDOUS DECOMPOSITION PRODUCTS

Thermal decomposition or burning may produce CO/CO<sub>2</sub>H<sub>2</sub>. The welding and cutting process may form reaction products such as carbon monoxide and carbon dioxide. Other decomposition products of normal operation originate from the volatilization, reaction or oxidation of the material being worked.

HAZARDOUS P	POLYMERIZATION		
May Occur	Will not Occur		
Х			

CHOVA OT ENGITICINO Elevated temperature and pressure and/or the presence of a catalyst.

# VII SPILL OR LEAK PROCEDURES .....

### STEPS TO BE TAKEN IF MATERIAL IS RELEASED OR SPILLED

Forms explosive mixtures with air (See Section V), immediately evacuate all personnel from danger area. Use self-contained breathing apparatus where needed. Remove all sources of Ignition if without risk. Reduce vapors with log or fine water spray. Shut off leak if without risk. Ventilate area of leak or move leaking container to well-ventilated area. Flammable gas may apread from leak. Before entering area, especially confined areas, check atmosphere with appropriate device.

WASTE DISPOSAL METHOD: Prevent waste from contaminating surrounding environment, Keep personnel away, Discard any product, residue, disposable container or liner in an environmentally acceptable manner, in full compliance with Federal, State and local regulations.

Page 3 of 4